



University of HUDDERSFIELD

University of Huddersfield Repository

Chen, Xun

Fundamental Study of Corrective Abrasive Machining Technology

Original Citation

Chen, Xun (2009) Fundamental Study of Corrective Abrasive Machining Technology. In: CIRP UK Meeting, 8th May 2009. (Unpublished)

This version is available at <http://eprints.hud.ac.uk/id/eprint/10621/>

The University Repository is a digital collection of the research output of the University, available on Open Access. Copyright and Moral Rights for the items on this site are retained by the individual author and/or other copyright owners. Users may access full items free of charge; copies of full text items generally can be reproduced, displayed or performed and given to third parties in any format or medium for personal research or study, educational or not-for-profit purposes without prior permission or charge, provided:

- The authors, title and full bibliographic details is credited in any copy;
- A hyperlink and/or URL is included for the original metadata page; and
- The content is not changed in any way.

For more information, including our policy and submission procedure, please contact the Repository Team at: E.mailbox@hud.ac.uk.

<http://eprints.hud.ac.uk/>




CIRP UK Meeting 8th May 2009





University of
HUDDERSFIELD

Fundamental Study of Corrective Abrasive Machining Technology

Dr Xun Chen



Advanced Machining Technology Group
Centre for Precision Technologies
School of Computing and Engineering



University of
HUDDERSFIELD

Precision machining technology

*Unique pioneer challenge in developing
next generation machining technology*



Current Research Themes

- Precision machining
 - Abrasive machining
 - Diamond turning
 - Finite element analysis and molecular dynamics
- Intelligent process monitoring and control
 - Contact detection using acoustic emission
 - Abrasive machining monitoring using AI techniques
- Knowledge support systems
 - Database / Knowledge warehouse

Centre for Precision Technologies

Educating tomorrow's professionals



University of HUDDERSFIELD

From the macroworld to the nanoworld

(The Hitchhiker's Guide to Nanotechnology, 2006)

Micro-machining is considered to cover the production of minute components and features from a wide range of materials, generally in the size range of 200 microns to a few nanometres and may also be known as micro drilling, micro cutting, micro milling, micro grinding and micro etching.

5

CPT Centre for Precision Technologies

University of HUDDERSFIELD

Challenge of nanometre scale machining

Sa < 1 nm
Form error < 0.1 μm

Aluminum (Al) Sa = 0.742 nm

- Spindle RPM: 2000
- Finish Feedrate: 7.5 mm/min
- Finish Depth of Cut: 2 μm
- Coolant: Odorless Mineral Spirits

Nickel (Ni) Sa = 0.924 nm



- Spindle RPM: 3000
- Finish Feedrate: 5 mm/min
- Finish Depth of Cut: 4 μm
- Coolant: Odorless Mineral Spirits

Grain boundary indicates the limitation of the conventional turning operation limitation.
What can be done?


It was claimed that grinding has no minimum depth of cut.

6




CPT Centre for Precision Technologies






Rigs for single grit grinding tests



AE signals of single grit scratch










Feature extraction of AE in grinding


Wheel rotational speed = 4000 rpm,
Feedrate = 4 m/s,
Workpiece materials: CMSX4.


	C%	P%	R%
1 μm cut	45	29	26
1 μm cut	45	47	8
0.1 mm cut	57	40	3








13



Laser irradiation imitating grinding thermal behaviour

Laser machine Lumonics:JK704 Nd:YAG

Wave length 1.06 μm

Pulse energy 1.36J


Maximum peak power 2.5kW


Laser irradiation time 0.06 ms

Focal length 120 mm


Light beam diameter 12 mm

Off-focal length 34~46 mm








(a)




(b)


14




University of HUDDERSFIELD

Grinding thermal behaviour monitoring by using thermal AE signatures



The NN created using AE signatures from laser irradiation



Grinding burn identification using the NN from thermal AE signatures

17

CPT Centre for Precision Technologies

University of HUDDERSFIELD

Pattern recognition for grinding defects

A Real Grinding Process (input)

Signal condition: Sensors (AE signal) → Impedance match & Amplifier → Data digitized & logging

Signal processing: Feature extraction: joint-time-frequency domain (wavelet packet) ← Quantification, Normalization, & Denoise etc


Pattern recognition: Feature optimization → Fuzzy classifier → Non-burn / Burn

Fuzzy c-mean cluster Minimum distance

Fuzzy recognition procedure

• Success rate 92.3%

Fuzzy recognition block diagram



More than 512 features: $X(m \times n)$

Feature equalization, Feature normalization, Feature calibration, Transitive closure calculation

Similarity measure & clustering

Less than 10 features

Burn status classification

Training & Classification

Selection & Optimisation

Feature extraction by wavelet packet and Joint Time-Frequency Analysis

18

CPT Centre for Precision Technologies

Support vector machine classification

Support vectors
Class II
Maximum margin
Optimal Hyperplane
Class I

1-5 measurements across workpiece

Test number

Ra measurements for each cut (3 Trials separated by lines)

CPT Centre for Precision Technologies

University of HUDDERSFIELD

19

SVM classification

Multiclass classification of FX and FY S spectrum (2mm)

Chatter
Actual cutting
Air grinding

Time

FX Spectrum

Time


FY Spectrum

Benefits of SVM:


- Small amount of training data required
- Small amount of classifying time

CPT Centre for Precision Technologies


University of HUDDERSFIELD



SVM Classification




Normal grinding






Chatter

Machine: Makino A55 CNC machine centre.
 Workpiece: Inconel 718.
 Wheel: VIPER wheel.
 Depth of cut: 1 mm;
 Grinding speed: 35 m/s;
 Workspeed: 1000 mm/min.


Machine: Makino A55 CNC machine centre.
 Workpiece: Inconel 718.
 Wheel: VIPER wheel.
 Depth of cut: 1 mm;
 Grinding speed: 55 m/s;
 Workspeed: 1000 mm/min.



21




Multi-classification of normal grinding, grinding chatter and burn using the GP






22

University of HUDDERSFIELD


Classification of grinding anomalies using genetic programming

No.	GP fitness function	Data set	Function Nodes	Test Score	Accuracy %
1	sum diff fitness	ICA Chatter and burn	+,', -, '/', *	32/40	80
2	sum diff fitness	*reduction: burn and no burn	+,', -, '/', *	36/40	90
3	sum diff fitness	*reduction: burn and no burn	=<, '=>, if	36/40	90
4	sum diff fitness	*reduction: burn and chatter	+,', -, '/', *	36/40	90
5	sum diff fitness	*reduction: burn and chatter	=<, '=>, if	38/40	95
6	classes overlap	ICA Burn and no burn	+,', -, '/', *	33/40	82.5
7	classes overlap	ICA chatter and no chatter	+,', -, '/', *	32/40	80
8	classes overlap	ICA chatter and no chatter	+,', -, '/', *	40/40	100
9	sum diff fitness	ICA chatter and no chatter	+,', -, '/', *	36/40	90
10	classes overlap	ICA Burn and no burn	+,', -, '/', *	40/40	100
11	classes overlap	*reduction: burn and no burn	+,', -, '/', *	40/40	100
12	classes overlap	*reduction: chatter & no chatter	+,', -, '/', *	40/40	100

*reduction: is based on the statistical window n-dimensional reduction technique

23

CPT Centre for Precision Technologies





Models of material removal



Preston material removal rate model $\frac{dz}{dt} = C_p p v_r$

Archard material removal volume model $V_w = K \frac{F_n s}{H}$

Polishing parameter Sp	Actual depth of cut δ [μm]
10	0.8
15	1.0
20	1.2
25	1.4
30	1.6
35	1.8
40	2.0
45	2.2
50	2.4
55	2.6
60	2.8
65	3.0
70	3.2
75	3.4
60	0.8 (SKD-61)

$$S_p = \frac{(V + f)p}{f H_v}$$

X. Wu, Y. Kita, K. Ioku (2007) 26




University of HUDDERSFIELD

Error compensation On-Machine Metrology enhanced

2D and 3D Metrology

Utilizing **UltraComp's™** LVDT, 2D and 3D data files of the part profile can be gathered including the machine axes

DIFFSYS® MC3 performs data import, graphically displays and auto-corrects the 3-dimensional part profiles from the LVDT measurement data to the desired part profile.



```

    graph LR
      A[Machine part with DIFFSYS® 3D X,Y,Z program] --> B[Gather data from X,Y,Z by point-to-point analysis or by scanning]
      B --> C[Output data file to 3rd party software]
      B --> D[Output data file to DIFFSYS®]
      C --> E[Quality inspection]
      D --> F[Auto-correct to desired tool path]
      F --> G[Re-machine 3D part to desired profile]
  
```


29

CPT Centre for Precision Technologies


University of HUDDERSFIELD

AE detection of contact


Before contact




After contact




3D Surface




SUPSTAND 2D Profiles Analysis




X Profile



Y Profile



Contact AE signals



30

CPT Centre for Precision Technologies

