

University of Huddersfield Repository

Stetsyuk, V., Crua, C., Pearson, R. and Gold, M.

Direct imaging of primary atomisation in the near-nozzle region of diesel sprays

Original Citation

Stetsyuk, V., Crua, C., Pearson, R. and Gold, M. (2014) Direct imaging of primary atomisation in the near-nozzle region of diesel sprays. In: The Universities Internal Combustion Engine Group (UnICEG) meeting, 17th September 2014, University of Nottingham. (Submitted)

This version is available at https://eprints.hud.ac.uk/id/eprint/27905/

The University Repository is a digital collection of the research output of the University, available on Open Access. Copyright and Moral Rights for the items on this site are retained by the individual author and/or other copyright owners. Users may access full items free of charge; copies of full text items generally can be reproduced, displayed or performed and given to third parties in any format or medium for personal research or study, educational or not-for-profit purposes without prior permission or charge, provided:

- The authors, title and full bibliographic details is credited in any copy;
- A hyperlink and/or URL is included for the original metadata page; and
- The content is not changed in any way.

For more information, including our policy and submission procedure, please contact the Repository Team at: E.mailbox@hud.ac.uk.

http://eprints.hud.ac.uk/



Direct imaging of primary atomisation in the near-nozzle region of diesel sprays

V. Stetsyuk, C. Crua

Centre for Automotive Engineering University of Brighton

R. Pearson, M. Gold

BP Global Fuels Technology

University of Nottingham, 17th September 2014









Contents

- Introduction
- Evaporative test conditions
- High-speed video and shadowgraphic microscopy
- Start of injection phase
- Steady-state period
- End of injection phase
- Conclusions
- Acknowledgement



Introduction

- The liquid fuel is injected at high velocity into a combustion chamber
- It atomizes into small droplets
- > The atomized fuel vaporizes and mixes with high-temperature air
- Combustion occurs after vaporized fuel mixes with air
- Mixing and evaporation occurs at microscopic scales
- > Initial stage of spray formation influences combustion process
- There is a need to study spray at macroscopic levels

Objectives

➤ To study morphology of fuel droplets during the injection process at microscopic scales in near nozzle region to aid model correlation






Evaporative test conditions

Rapid Compression Machine (RCM) is:

A single cylinder Ricardo Proteus two-stroke test engine



Bore: 135 mm

Stroke: 150 mm

Displacement: 2.2 l

RPM: 500

Quiescent air motion at TDC

P_{ini}: 30-200 MPa

• ICP: up to 12 MPa

TDC temperatures 540-850 K



Evaporative test conditions (cont.)

Target operating conditions

O ₂	In-cylinder Temp, K	In-cylinder Density, kg/m³	ICP, bar	Inj. Pressure, bar	Fuel	Inj. Duration Based on trigger, ms
21%	700	22.8	48	500, 1000, 1500	n-dodecane	1.5


Specifications for the injector (IFPEN 201.02 ECN spray A)

Description	Value		
Туре	Bosh solenoid-actuated, generation 2.4		
Nominal nozzle outlet diameter	0.090 mm		
Nozzle K factor*	1.5		
Nozzle shaping	Hydro-erosion		
Mini-sac volume	0.2 mm ³		
Number of holes	1 (single hole)		
Orifice orientation	Axial (0° full included angle)		





High-speed video and microscopy





High-speed video and microscopy system

Long-distance microscope








CAVILUX Smart 640 nm pulsed diode laser light source


Phantom V710 high-speed camera 80-200 mm Nikon AF Nikkor




Start of injection (HSV)



Motored @ ICP 4.5 MPa







- Dashed line is standard deviation
- IFPEN injector 201.02 at 900K 22.8 kg/m³
- Good correspondence with liquid and vapour IFPEN data



Start of injection (Microscopy)

Liquid-vapour mixture exiting the nozzle hole for 0.295 ms ASOI P_{ini} = 150 MPa, ICP 4.8 MPa





Fuel jet eventually pierces through this vapour cap



Start of injection (Microscopy)


Vapour pre-jet was also reported for other injectors e.g. Delphi 1.3 7-hole, 135µm VCO and fuel (ULSD)

The vapour pre-jet can be caused by:

- Expansion of cavitation pockets after previous injection
- Ingestion of in-cylinder gases after previous injection
- Heating and evaporation of fuel inside orifice
- Can be ignited (if it is fuel vapour)
- Modelling may need to account for in-nozzle fluid properties




Steady-state (1.0-3.0 ms)






End of injection (3.0-3.6 ms)






End of injection in ECN injector

 P_{inj} =100 MPa, 3.7 ms ASOI



- Large 'slow' droplets
- Micro-injection events
- Random droplet trajectory
- > Spherical droplets

Micro-injection events after EOI $P_{inj} = 150 \text{ MPa}$ for 3.6 ms ASOI




Start of micro-injection event


Droplets from 'main end of injection'

Secondary micro-injection events in the ECN injector could be caused by: The needle bouncing from the seat or by expansion of the fluid in the sac



End of injection (cont.)





- ➤ Large ligaments as well as highly deformed droplets are observed for low P_{ini}
- Hard to process in order to extract statistics


Long structures (~420 µm)

- Long irregular ligaments present significant modelling challenges for
 - a) initialisation of emerging fluid
 - b) modelling of subsequent evaporation and transport

Non-spherical droplets

3D shape reconstruction, is needed in order to estimate the droplet surface area and volume

End of injection (cont.)





Conclusions

- > Long injection process (compared to trigger duration) due to single-hole design
- > Vapour pre-jet for a range of pressures of circa constant length was observed
- > Secondary injection even due to possible needle bouncing or fuel expansion in sac
- > Large droplets and long ligaments with low velocity for low injection pressures
- Quantitative velocity field of droplets or gas phase can be obtained



Acknowledgments

Equipment

EPSRC Engineering Instrument Pool

Funding

BP Global Fuels Technology

EPSRC (grant EP/K020528/1)